

IMPORTANT:

Please read before
opening & unpacking the
La Bassine Pool.

Follow the enclosed
instructions for safe use,
cleaning & proper assembly.

Before unpacking, please note how the equipment is packed in its box, so repacking the tub when you are finished will be easier.

SEE REVERSE SIDE



Thank you for choosing to rent a La Bassine Pool!

The following are recommendations intended to facilitate ease of use of the La Bassine Pool:

Before unpacking, please note how it is packed to ensure that re-packing the tub when you are finished will be easier. Unpack the equipment mindfully, exercising care to avoid damaging the materials and contents. Please do not unfold the pool until it has acclimated to room temperature. Use the electric air pump and its fittings to inflate and deflate the tub.

Please read and follow the enclosed Instruction Guide prior to and during assembly. Notice the section labeled, "Accessories not provided, but may be desired or necessary."

You do not need to fill with water as a test run, **but make sure the hose fits the faucet with the particular adapter provided. If it does not fit or work properly, you must purchase an adapter that does or find another faucet to use!**

Filling the tub and maintaining an accurate temperature read:

Always FILL the tub with from a **hot water tap** with the **clean white lead-free hose provided. Do not use this hose for draining the tub.**

Important: You must fill the tub with warm water at the the desired temperature, roughly 99° F.

To maintain an accurate temperature reading, you must ensure that the water in the tub has been thoroughly mixed, both when filling as well as when standing unused. Thermal layers occur when the water has been standing in the tub. The thermometer floats at the top, reading just the first six inches or so. Hot water naturally rises to the top, while cold water naturally sinks to the bottom. Be sure to keep the water mixed and you will have more success at maintaining an accurate temperature. This means stirring the water every hour or so if it is left standing. If the tub begins to cool before the birth, you may need to remove some of the current water, and pour in hot water. Do not place the white hose in any water that has been used.

After using the tub:

Begin the draining and cleaning process as outlined in the Instruction Guide. It is best to empty the tub immediately after use after removing any floating particles. **Use the dark hose for emptying the tub, and ONLY for emptying the tub.**

After the tub is drained and the disposable liner is disposed, follow the instruction as outlined on the document titled, "What should you do with the La Bassine Pool after the birth?"

Your attention to these considerations is greatly appreciated!!

If you have any questions, please call Esther at (510) 725-5456.